



WET AREA COMPONENTS

Spindle and Mixer Flange

Australian Design No 202116047

Installation Guide

1. Ensure the breach is set back to correct position so that the front of the breach (spindle housing) is flush with the front of the substrate.
2. Push the flange into position around the spindle and breach (spindle housing) to check fit.
3. Once fitted, remove the flange, and apply adhesive to the back of the flange.
4. Re-fit and stick the flange to substrate.
5. Apply silicon to the rubber seal around breach or mixer for extra protection.
6. Waterproof into flange.