



WET AREA COMPONENTS

Raised Base Water Stop Flanges

Australian Design No's 202116039, 202116040

Installation Guide

1. Mark out the size of the recess required.
2. If the recess is in a corner, miter two brackets to achieve the required size. Glue and screw the pieces together. If only one side across the front of the recess, cut to size and install an end panel.
3. Install noggins or timber supports below the substrate where the component is to be installed (timber floor only).
4. Cut out a channel in the substrate to accommodate the components base plate. If concrete, mark fixing positions and install plugs into the concrete to accept the fixing screws.
5. Apply adhesive to underside of bracket and fix into position with fixing screws. Note – if a shower screen is to be fitted, install the shower screen wall bracket flanges at this stage.
6. Once installed, the recess can be waterproofed and the screed installed.