



WET AREA COMPONENTS

Channel and Grate Flanges

Australian Design No's 202116034, 202116035,
202116036

Installation Guide

1. Install noggins/timber below where the leak control channel is to be installed to allow for support. Ensure there are no obstructions around the waste connection.
2. Once the substrate and wall linings within the recess have been installed, the leak control channel can be installed. This leak control channel is sealed to the substrate and wall linings, and fixed through the wall linings and substrate with screws.
3. Once fixed into position, the channel is waterproofed over when the rest of the recess is waterproofed.
4. Install the recess tiling, leaving enough room for the stainless-steel channel and grate to be dropped into position.
5. Set the stainless-steel tray finishing height with the packers provided. Fix the packers with sealant to prevent movement.
6. Drop the stainless-steel tray into position. Caulk the perimeter of the stainless-steel tray to the floor and wall tiles as required.
7. Connect the waste trap and plumbing to the channel.