



WET AREA COMPONENTS

Tiled Floor Water Stop

Australian Design No's 202116043, 202116044

Installation Guide

1. Mark out where the shower screen is to be installed.
2. Install noggins beneath this location to provide fixing support for the water stop angle.
3. Leave a 55mm channel of flooring substrate over noggins where the shower screen is to be installed. If concrete, mark fixing positions and install plugs into the concrete to accept the fixing screws.
4. Install the water stop angle into the channel. Use sealant on the underside of the water stop angle to secure it to the substrate. Fix to noggins with screws.
5. Waterproof shower recess substrate, including the water stop angle.