



WET AREA COMPONENTS

Shower Screen Wall Bracket

Australian Design No 202116045

Installation Guide

1. Install noggins or flat back stub (preferable) into wall frame on either side of the shower recess where the shower screen would be installed.
2. Find the shower screen frame position and mark centre.
3. Mark 30 mm from the centre line towards the inside of the recess, and 20 mm towards the outside. This will give a 50 mm space to install the bracket.
4. Install the substrate on each side of the line, leaving the required 50 mm to install the shower screen bracket. (Alternatively, if fully sheeted, mark out in the same manner, but cut out the 50 mm section of sheet required.)
5. Mark out bracket fixing points, using the shower screen bracket as a guide.
6. Drill an 18 mm hole at each fixing point.
7. Check the fit of the bracket. Ensure drilled holes line up with the correct place of the bracket. Once the correct alignment is achieved, the bracket can be removed.
8. Apply adhesive to the back of the bracket, re-insert into position and screw to secure.
9. Waterproof over bracket.