



WET AREA COMPONENTS

Hob Water Stop Flanges

Australian Design No's 202116037, 202116038

Installation Guide

1. Mark out the size of the recess and hob location.
2. Install noggins or timber supports beneath the flooring so the component can be secured (timber floor only).
3. Cut out a 72 mm channel in the flooring to accommodate the hob (timber floor only). If concrete, mark fixing positions and install plugs into the concrete to accept the fixing screws.
4. Apply adhesive to the underside of the component and screw into position.
Note – install the shower screen wall bracket flanges at this stage.
5. Once installed, the recess can be waterproofed and screeded.