



WET AREA COMPONENTS

Shower Screen Floor Bracket

Australian Design No's 202116041, 202116042

Installation Guide

1. Mark out where the shower screen is to be installed.
2. Install noggins beneath this location to provide fixing support for bracket.
3. Leave a 55mm channel of flooring substrate over noggins where screen is to be installed (timber floor only). If concrete, mark fixing positions and install plugs into the concrete to accept the fixing screws.
4. For timber floor, install bracket into channel. Use sealant on the underside of the bracket to secure it to the substrate. Fix to noggins with screws.
5. For concrete floor, If concrete, mark fixing positions and install plugs into the concrete to accept the fixing screws. Screw into position.
6. Waterproof the shower recess substrate and floor bracket.