



WET AREA COMPONENTS

# Recess Accessory Bracket

Australian Design No 202116046

## Installation Guide

1. Mark out the position of the fitting (i.e. shower rail). Mark the centres.
2. Install noggins behind the substrate.
3. Install a screw or nail into noggins at required centres so when the substrate is installed, the noggins can be located. Alternatively, record measurements for use later.
4. Mark the centres on substrate.
5. Drill an 18mm hole into the noggin at the required centre.
6. Push bracket into the hole and roughly mark out sides of the bracket rebate.
7. Remove the marked-out section of substrate.
8. Install the fixing bracket and check for fit.
9. Remove the bracket and apply adhesive and screw into position.
10. Waterproof the fixing bracket (waterproof over the protruding sides of the bracket).